

M109-R Front Blinker

- 1 – Remove headlight bezel.**
- 2 – Remove 2 philips head screws underneath stock turn signals.**
- 3 – Remove stock turn signals. Cut off stock wiring connectors.**
- 4 – Connect to new front turn signals.**
- 5 – Install new turn signals and attach with new alan screw – (supplied with light).**
- 6 – Connect stock connectors and test lights.**

Thanks – Raw Design

Disclaimer: Off-road use only. Due to machining and welding process, slight irregularities are common with the finish of front marker lights. This is normal.