

M109-R Rear Blinker

- 1 – Remove seat and back body panel.**
- 2 – Remove 4, 10mm bolts that hold the stock plastic turn signal holder on.**
- 3 – Cut off the turn signal plate holder flush - a utility knife works well.**
- 4 – Reinstall the newly trimmed piece with the 10mm bolts and place the back body panel back on.**
- 5 – Take the new turn signal bracket and place under the back body and line up to the edge, the ends of the signal bracket should touch or be close to the seat supports. Mark the 3 holes with a small drill bit.**
- 6 – Take the body panel back off and drill the 3 marked holes with a 3/16 drill, then install signal bracket. Run the wires up to the stock harness holder, cut off the stock connectors from your old turn signals and connect to the new one.**
- 7 – Reinstall back body panel and adjust the light as necessary, then test your blinkers.**
- 8 – Reinstall your seat and ride on.**

Thanks – Raw Design

Disclaimer: Off-road use only.