

# **Street Magic® Amber *BRIGHTSIDES™* Install Instructions**

- 1) Using a suitable pry tool, carefully remove the stock front fender reflector taking care to not damage fender or the paint.  
(see PIC #1)
- 2) Thoroughly clean this area of any old tape and glue. Once clean, wipe down this area with the enclosed 3M promoter pad.  
(see PIC #2)
- 3) Hold BRIGHTSIDE light up to fender noting location where wire meets fender, drill ¼ inch hole in fender for wire to pass through. **\*\*\*NOTE\*\*\* When drilling fender take extra care not to allow drill to damage tire**  
(see PIC #3)
- 4) Insert wire from BRIGHTSIDE through hole in fender and remove backing from tape, firmly press BRIGHTSIDE into place. Be careful to align BRIGHTSIDE light in the fender recessed area.  
(see PIC #4)
- 5) Slide the 2 3M mounting blocks onto BRIGHTSIDE wire by passing wire through slots in mounting block.  
(see PIC #5)
- 6) Although shown on the outside the fender in the picture to better show their mounting locations, treat the underside of the fender with the 3M promoter pad and stick the 3M mounting blocks with wire roughly in these areas as shown on the **UNDERSIDE** of the fender to hold wire in place.  
(see PIC #6)
- 7) Remove the front fender tip light from fender. Using the supplied Posi-Tap connectors hook wires from BRIGHTSIDE to wires going to fender tip light as follows. **WHITE** wire from BRIGHTSIDE to **ORANGE** wire going to fender tip light and **BLACK** wire from BRIGHTSIDE to **BLACK** wire going to fender tip light. If you have any questions on the proper use of the Posi-Tap connectors please visit [www.posi-lock.com](http://www.posi-lock.com)
- 8) Reinstall front fender tip light into fender, test operation.  
(see PIC #7)
- 9) Repeat procedures 1 through 8 for remaining fender.



PIC #1



PIC#2



PIC #3



PIC#4



PIC #5



PIC#6



PIC#7