

## Street Magic Dynamic Clusters Installation Instructions

1. Remove turn signal lenses.
2. Route orange and red wires through turn signal housing to tail light, this may require drilling a hole in the back of the reflector. Repeat for other turn signal housing.
3. Connect orange wires to running light power source using supplied Posi-Tap
4. Connect red wires to brake light power source using supplied Posi-Tap
5. Insert base into stock receptacles
6. Reinstall Lenses.
7. Check operation in all modes: running, brake, turn.

