

This mount may not be legal in all states.

Attention, this plate mount is designed to have the plate mounted on the inside of the mount. the holes wont line up otherwise. you may still have to reef or oblong the holes in the plate to get your bolts in for the plate. Use the polished washer on the outside of the plate and the 2 other ones on the inside of the mount up against the hub to space it out so nothing rubs the hub. You will need a 14 mm allen wrench or might get a 9/16" standard to tighten up the mount bolt. Have the mount just a little higher than you want it to be when tight and pull it down to where you want it as you finish tightening the allen screw. The light pod was meant to mount under the left fender strut so it shines down on threw plate, just wire it into the tail light wire. Let me know what you think Gregg Florance.916-652-7181

