

Street Magic® Cycle Products

HID Conversion Kit



1. With motorcycle off and in a secure position, remove the stock headlamp.
2. Remove the stock bulb from the headlamp and unplug from stock connector.
3. Install HID bulb into stock location.
4. Locate suitable mounting location for ballast either inside headlight bucket, behind fairing or other location. Securely mount ballast with enclosed double sided tape.
5. Plug stock connector into HID input connector. If unit is equipped with a relay, connect black wire to a good ground and connect red wire to positive of battery. Secure wires with tie wraps.
6. Reinstall the stock headlamp.
7. Check operation of HID in all modes with motorcycle running and motorcycle not running.

Note: These kits are not DOT approved, and may not be approved in all states. Please check local and state laws before using.

