

Street Magic[®]
Magic Power Blokz[™]
Quick, Convenient, Safe and Secure[™]

Installation Instructions

- 1.) First, disconnect negative cable from battery.
- 2.) Next, disconnect positive cable from battery.
- 3.) Re-attach **only** the positive battery cable and *Magic Power Blokz*[™] containing fuse holder to battery positive terminal.

NOTE

Each *Magic Power Blokz*[™] will allow for up to 4 additional leads to be attach to each unit. *Magic Power Blokz*[™] will support a 15 amp load at 12 volts. Any accessory requiring a higher current draw than this will need to be wired into a different power source.

- 4.) Locate the positive lead of each accessory you wish to connect using the *Magic Power Blokz*[™] and cut and strip wire end to allow for insertion into *Magic Power Blokz*[™]. Each wire should have insulation striped back according to "gauge depression" on back side of *Magic Power Blokz*[™].
- 5.) After wire is striped according to gauge, fully lift orange lever on any *Magic Power Blokz*[™] port until it locks in open position. Fully insert wire into *Magic Power Blokz*[™] and snap lever into closed position. Repeat procedures 4 and 5 for all wires as needed.
- 6.) Once all positive wires have been connected, attach only the battery negative cable and remaining *Magic Power Blokz*[™] to negative battery terminal.
- 7.) Repeat procedures 4 and 5 for all negative wires as needed.
- 8.) Check all connections and test accessories for proper operation.

Now you're done and have taken that once dangerous and unsightly mess of connections and made all of your 12 volt accessory connections

Quick, Convenient, Safe and Secure[™]

