

***Street Magic®* Spyder Double Play Install Instructions**

- 1) Remove instrument cluster from Spyder by following instructions on page 107 of owners manual.
- 2) Once removed, unhook connector to detach instrument gauge cluster from Spyder.
- 3) Locate and unplug harnesses going to each front directional.
- 4) Plug one pair of connectors from Double Play unit to right side directional connectors.
- 5) Plug remaining pair of connectors from Double Play unit to left side directional connectors.
- 6) Remove rear under-tail cover to gain access to license plate light as per instructions on page 94 in your owner's manual. Once removed, locate 2 pin connector for license plate light. This connector will have an orange and black wire in it.
- 7) Route orange wire from Double Play unit under body panels and along frame until it reaches the license plate light connector in rear under tail area. Remove any body panels you may need to allow for wire routing.
- 8) Using supplied Posi-Tap connector, tap orange wire from Double Play unit into orange wire in license plate light connector.

*****NOTE*****

If you have question on how to use the Posi-Tap connector please see their web site

@ <http://www.posi-lock.com/posiplug.html>

- 9) Reinstall instrument gauge cluster.
- 10) Test operation and reinstall any body panels removed as well as rear under tail cover.

