

Street Magic® Spyder Footrest Bracket Installation

Please read all instructions carefully and gather the tools needed before beginning this project.

If you are not completely confident in your ability to successfully accomplish this upgrade, please seek the services of a qualified motorcycle mechanic.

NOTE: These footrests are NOT made to sustain the rider's full weight. You should NEVER stand on these units as this will cause the frame support to bend and/or break, resulting in damage to your Spyder and/or personal injury or death.

These units are designed ONLY to carry the weight of the driver's feet!

- 1.) Remove all lower matte black body panels from both sides of the Spyder. (see pictures #1,#2,#3 & #4)
- 2.) Locate left side bracket from kit. Left side bracket is the one with 3 holes in it.
- 3.) Line up the front hole in bracket with hole in frame support. Repeat for rear hole in bracket. Insert bolts from bottom with washer and nut on top. Just snug bolts at this time but do not fully tighten. (see picture #5)
- 4.) Mark location for remaining hole in bracket on frame support. Drill hole using 3/8 inch drill. (see pictures #6 & #7)
- 5.) After drilling hole insert remaining bolt through hole from bottom with washer and nut on top.
- 6.) Fully tighten all 3 bolts at this time.
- 7.) The lower black splash pan requires a relief cut into it for the bolt head. Hold lower splash pan in place and make mark on inside of pan by pushing pan against bolt head. Remove splash pan and use razor cutter or die grinder to cut hole for bolt head from footrest in pan. (see picture #8)
- 8.) Bolt right side bracket to frame support with 2 bolts through holes in bracket. Again, bolts go from bottom to top with washer and nut on top side. (see picture #9)
- 9.) Mark location for bolt head in splash pan and cut as necessary. (see picture #10)
- 10.) Reinstall all body panels.
- 11.) **If you purchased our adjustable link style brackets.** Install adjustable link to hole in bracket using enclosed hardware. Install adjustable link on outside of bracket with nut on inside of bracket. (see picture #11)
- 11.) Install your choice of foot pegs as per peg manufacturer's instructions. (see pictures #12 & #13)

NOTE: These footrests are NOT made to sustain the rider's full weight. You should NEVER stand on these units as this will cause the frame support to bend and/or break, resulting in damage to your Spyder and/or personal injury or death.

These units are designed ONLY to carry the weight of the driver's feet!

Street Magic® Spyder Footrest Bracket Installation



#1



#2



#3



#4



#5



#6



#7



#8



#9



#10



#11



#12



#13