

Street Magic® Cycle Products

SS6 Signal Stabilizer™ Installation Instructions

Fits 2010-2012 Street Glide & Road Glide (Does not Fit CVO models)

1. Locate connector block for taillight/turn signals located under left side panel on 2010 FLHX or under seat on Road Glide models.
2. Unplug main harness connector from fender harness connector.
3. Plug Signal Stabilizer™ in between these two connectors. Mount Signal Stabilizer in secure location.
4. Connect Red wire from Signal Stabilizer to Positive of battery through 3 amp fuse.
5. Attach Black wire with terminal ring from Signal Stabilizer™ to NEGATIVE of battery.
6. Test signals for proper operation. Test Alarm for proper operation, if equipped.

