

Street Magic[®] Cycle Products

SS6 Signal Stabilizer[™] Installation Instructions

Fits 2010-2011 Street Glide, Road Glide, Wide Glide

- 1. Locate connector block for taillight/turn signals located under left side panel on 2010 FLHX or under seat on other HD models.**
- 2. Unplug main harness connector from fender harness connector.**
- 3. Plug Signal Stabilizer[™] in between these two connectors. Mount Signal Stabilizer in secure location.**
- 4. Test signals for proper operation. Test Alarm for proper operation, if equipped.**