

# Street Magic® Cycle Products

## SS8 Signal Stabilizer™ Installation Instructions

**Fits 2010-2012 Street Glide Screaming Eagle , 2009 Road Glide Screaming Eagle**

1. **Locate connector block for taillight/turn signals located under seat. Unplug main harness connector from fender harness connector.**
2. **Plug Signal Stabilizer™ in between these two connectors. Mount Signal Stabilizer in secure location.**
3. **Connect Red wire from Signal Stabilizer to Positive of Battery through 3 amp Fuse.**
4. **Attach Black wire with terminal ring from Signal Stabilizer™ to NEGATIVE of battery.**
5. **Test signals for proper operation. Test Alarm for proper operation, if equipped.**

