

Street Magic® Cycle Products

SS8 Signal Stabilizer™ Installation Instructions

Fits 2010-2011 Street Glide Screaming Eagle , 2009 Road Glide Screaming

- 1. Locate connector block for taillight/turn signals located under seat. Unplug main harness connector from fender harness connector.**
- 2. Plug Signal Stabilizer™ in between these two connectors. Mount Signal Stabilizer in secure location.**
- 3. Test signals for proper operation. Test Alarm for proper operation, if equipped.**