

Street Magic Trailer LED Light Bar Installation Instructions

Contents:

- 1 Light Bar
- 1 3M Promoter Pack
- 6 Tie Wraps
- 6 Quick Splice Connectors
- 2 Heat Shrink Tubes

1. Select the surface that light bar will be mounted and clean surface with 3M Promoter pack.
2. Allow to dry for 2-3 minutes.
3. Remove red liner and mount light bar onto Trailer.
4. Connect black wires to vehicle grounds.
5. Solder Single Red Wire (bottom of Y) of Dual Circuit (Y) to one Red wire of Light Bar, cover with heat shrink tube. Repeat for other side.
6. Connect remaining red wire of Left Y to vehicle left brake/turn wire, connect remaining red wire of right Y to vehicle right brake/turn wire using supplied Quick Splice Connectors. Connect orange wires to vehicle running light power source. Tie wrap wires so that they do not interfere with normal operation of trailer or door.
7. Test operation of light bar in all modes.



Disclaimer: Custom Dynamics LLC assumes no liability of any kind as a result of conversions or additions to your vehicle.