



LARGE HALOGEN SILVER BULLETS 2321

WITH FRONT FORK MOUNTS

FITS: H-D 41MM WIDE GLIDE (UNSHROUDED), '06-'07 DYNA WITH 49MM FRONT ENDS, AND 39MM NARROW GLIDE FRONT ENDS

PARTS INCLUDED

- 39mm/49mm Front End Kits:
2 39mm/49mm Fork Mounts
2 5/16" I.D. Internal Tooth Lock Washers
2 5/16"-18 x 1" Button Head Cap Screws
2 3/8"-16 x 1-3/4" Flat Head Cap Screws
41mm Front End Kits:
1 41mm Mount - Left
1 41mm Mount - Right
2 5/16" I.D. Internal Tooth Lock Washers
2 5/16"-18 x 2-3/4" Socket Head Cap Screws
2 7/16"-20 x 1-3/4" Hex Bolt
2 7/16" I.D. Split Lock Washer
2 Large Halogen Silver Bullet Lights
(Light Bodies Tapped 5/16"-18, wire exits through Light Housing)
1 Anti-Seize

Please read and understand entire instructions before starting installation.

THANK YOU FOR CHOOSING KÜRYAKYN!

IN ORDER TO PROTECT YOU AND OTHERS FROM POSSIBLE INJURY AND/OR PROPERTY DAMAGE OR LOSS, PLEASE PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS AND ATTENTION NOTES REGARDING THE USE AND CARE OF THIS PRODUCT.

ATTENTION! This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality.

ITEMS RECOMMENDED FOR INSTALLATION

- Test Light
• Service Manual

ATTENTION! Be sure to use the supplied anti-seize on all threaded fasteners before installation. This will reduce galling and make future removal of the fasteners easier.

TOOLS SUGGESTED

3/16" 7/32", 1/4" Allen wrenches, 5/8" Combination wrench, Splicing and insulating supplies.

STRICTLY OBSERVE THE FOLLOWING GUIDELINES IN ORDER TO USE THE PRODUCT PROPERLY AND AVOID POTENTIALLY DANGEROUS ACCIDENTS.

-cont.-



CUSTOMER SERVICE
877.370.3604 (toll free)

INSTALLATION QUESTIONS
techsupport@kuryakyn.com
or call 715.247.2983

LIMITED WARRANTY
Kuryakyn warrants that any Kuryakyn products sold hereunder, shall be free of defects in materials and workmanship for a period of one (1) year from the date of purchase by the consumer excepting the following provisions:

- Kuryakyn shall have no obligation in the event the customer is unable to provide a receipt showing the date the customer purchased the product(s).
• The product must be properly installed, maintained and operated under normal conditions.
• Kuryakyn makes no warranty, expressed or implied, with respect to any gold plated products.
• Kuryakyn shall not be liable for any consequential and incidental damages, including labor and paint, resulting from failure of a Kuryakyn product, failure to deliver, delay in delivery, delivery in non-conforming condition, or for any breach of contract or duty between Kuryakyn and a customer.
• Kuryakyn products are often intended for use in specific applications. Kuryakyn makes no warranty if a Kuryakyn product is used in applications other than intended.
• Kuryakyn electrical products are warranted for one (1) year from the date of purchase by the consumer. Components of Kuryakyn products containing L.E.D.s will be warranted for defects in materials and workmanship for 3 years from the date of purchase.
• Kuryakyn makes no warranty of any kind in regard to other manufacturer's products distributed by Kuryakyn. Kuryakyn will pass on all warranties made by the manufacturer and where possible, will expedite the claim on behalf of the customer, but ultimately, responsibility for disposition of the warranty claim lies with the manufacturer.

ABOUT OUR CATALOG
You'll find all our innovations for H-D, GL and Metric Cruisers in our annual catalogs. Order online today-select the "CATALOGS" icon. Each Kuryakyn® product comes with a Proof-of-Purchase good for a complimentary catalog. Details in packaging.

Be sure to ask your local dealer about other Kuryakyn products, the motorcycle parts and accessories designed for riders by riders.

©2005 Kuryakyn USA® All Rights reserved.



## NOTES

Silver Bullets are not D.O.T. approved and are intended for use as auxiliary running, turn, or brake lights only.

Universal Silver Bullets can be installed just about anywhere. Küryakyn's P-clamps and Two-Piece Fork Mounts work great to attach Silver Bullets to engine guards, frame tubes, or fork tubes.

## PROCEDURE FOR 39MM/49MM FRONT ENDS

**STEP 1** Remove the pinch bolt on the lower triple clamp.

**STEP 2** Place the 3/8" Flat Head Cap Screw through the 39mm/49mm mount, and replace the stock pinch bolt with this assembly. (PIC.1) Tighten to 30–35 Ft/Lbs.

**STEP 3** From the back side, so the threads will face outward, insert the 5/16" button head through the mounting bracket, followed by a 5/16" lock washer. Install the silver bullet light to this fastener, level, and tighten securely. See PIC. 2.

**STEP 4** Repeat this procedure on the other side of the bike.

**STEP 5** Neatly route the wires to your chosen splice point and secure the wires neatly with cable ties.

**STEP 6** Proceed to wiring section.

## PROCEDURE FOR 41MM FRONT ENDS

**STEP 1** Remove the pinch bolt from the lower triple clamp.

**STEP 2** See PIC. 3. Assemble the light mount with the 7/16" Hex bolt and split lock and attach to the fork where the stock pinch bolt was removed. Tighten to 30–35 Ft/Lbs.

**STEP 3** From the back side, so the threads face outward, slide the 5/16"–18 x 2-3/4" SHCS into the mounting bracket — followed by the 5/16" internal tooth lock washer. Install the Silver Bullet light with this fastener. See PIC. 4.

**STEP 4** Repeat this procedure on the other side of the bike.

**STEP 5** Neatly route the wires to your chosen splice point, and secure the wires neatly with cable ties.

**STEP 6** Proceed to the wiring section.

## PROCEDURE FOR SINGLE CIRCUIT HALOGEN DRIVING WIRING

The black wire from the Silver Bullet is the power wire. The ground is the Silver Bullet Housing.

### **SILVER BULLET WIRING:**

Black Wire — Power (Hot)  
Silver Bullet Housing — Ground

Wiring and accessory circuits are protected by a 10 or 15 amp circuit. Adding these lights will place an approximate additional 4 amp draw on this circuit. This additional load may be too much amperage on that circuit and may cause a circuit breaker to trip, or blow a fuse. You may want to wire these to an accessory circuit or use a relay kit, Küryakyn P/N 2328.

# Küryakyn®

PIC. 1



PIC. 2



PIC. 3



PIC. 4



PAGE

2

*Ride On!*

HALOGEN SILVER BULLETS

INSTALLATION