

Honda VT-1100 Ace, Aero, Shadow Air Horn Installation Instructions

1. Remove the radiator cover bolt located at the bottom of the radiator.
2. Remove the left frame side cover.
3. Remove the stock horn. Re-route the wires up and over the radiator on the left side. Re-install the radiator cover bolt.
4. Install the horn mounting bracket to the frame with the loop to the inside of the frame as pictured.
5. Install, align and tighten the horns. (You may want to put a small twist or bend in the bracket using a crescent wrench.)
6. Attach the horn wire extension lead and air hose. Route under and along left side of frame behind the engine and over the regulator. (finned box with wires attached)
7. Using the hose clamp provided, secure the compressor to the lower horizontal tube located at the bottom of the frame behind the engine. Be sure the wire terminals are pointing to the left side of the bike and the compressor is rotated up enough so that it is no lower than the bottom of the engine. Also be sure the hose clamp is tight.
8. Attach the hose (cut to desired length) and (-) negative white ground wire and the (+) positive red wire.
9. Attach the (-) negative white ground wire to the regulator bolt.
10. Route the red wire and horn extension up near the battery positive connection.
11. Attach the fuse to the positive battery terminal.
12. Connect the relay per the wiring diagram, cable tie the relay to your battery overflow tube or the frame tube making sure to face the terminals down.
13. Cable tie all the wires and hoses neatly in place making sure not to pinch air hoses.
14. Test your horns, Good Job
15. Re-install the side cover.

RIVCO Products, Inc
440 South Pine Street
Burlington, WI 53105
262.763.8222
rivcoproducts.com

