

Street Magic M109 Side Mount Licence Plate Installation Instructions

- 1) Remove seat, rear cowl or passenger seat, rear fender and the left side panel as per manufactures guidelines. (see Fig 1)
- 2) Remove the lower black swing arm cover on the left side as per manufactures guidelines. (see Fig 2)
- 3) Remove the two bolts that attach the left passenger peg to the frame. (see Fig 3)
- 4) Remove the backing plate from the bracket and decide on which way you would like your licence plate mounted, either vertical or horizontal. Remove the four bolts in the rear of the plate bracket for this positioning. **DO NOT** put the backing plate on at this time.(see Fig 4)
- 5) Using the supplied allen bolts, mount the bracket and the rear passenger peg removed in step 3 to the frame making sure that the plate bracket is closest to the frame of the bike. (see Fig 5).
- 6) With the rear fender out of the way, locate the two wires for the original license plate light. This will be the GRAY and Black with white stripe wires in the harness. Using the supplied Posi-tap connectors, put one of the Posi-tap connectors on the GRAY Wire and one on the BLACK with white stripe (see Fig 6). If you have questions on how to use Posi-Tap connectors Please see: www.posi-lock.com
- 7) Mount your License plate and supplied plate frame to the backing plate running the wire for the plate frame through one of the channels in the backing plate and out the hole on the center. (see Fig 7).
- 8) Route the wire through the channel in the bracket and out the hole in the side of the bracket. (see Fig 8) Then route the wire between the frame rail and the inner rear fender. Secure the wire to the passenger peg bracket with one of the supplied zip ties (see Fig 9). Then continue to secure the wire to the rest of the rear fender wiring harness. (see Fig 10).
- 9) Insert the WHITE wire from the license plate frame into the Posi-tap connector on the GRAY wire and insert the BLACK wire from the license plate frame to the Posi-tap connector on the BLACK wire with the white stripe.
- 10) Test operation of the L.E.D.'s in the plate frame by turning the key to on (see Fig 11). Put side panels fender, rear cowl and seat back on and enjoy!!!



Figure 1



Figure 2



Figure 3



Figure 4



Figure 5



Figure 6



Figure 7



Figure 8



Figure 9



Figure 10



Figure 11