

Street Magic V-Rod Triple Play Instructions

- 1) Gain access to rear turn signal and tail light wiring connectors by removing the tail light from bike.**
- 2) Unplug wire connectors going to both rear turn signals and to the tail light.**
- 3) Plug the two port connectors with the purple and black wires from Signal Stabilizer unit between the wires for left side turn signal.**
- 4) Plug the two port connectors with the brown and black wires from Signal Stabilizer unit between the wires for right side turn signal.**
- 5) Plug the 4 port connector between the wires for the tail light.**
- 6) Slide Signal Stabilizer unit into opening in rear fender above tail light. Secure with double sided tape or tie wraps.**
- 7) Re-install tail light and test operation.**

