

Installation Instructions:

Caution: LED Board will break if bent side to side

- 1) Measure Circumference of Fork
- 2) Cut D-channel Tube to fork circumference (can be cut with channel cutters)
- 3) Cut LED Board to nearest length of D-channel Tube from step #2 (can be cut every 0.6", Board can be cut by snapping it over a straight edge)
- 4) Insert board into D-Channel Tube, center board in tube. Seal with silicon sealer, end caps are not used, allow silicon to setup before continuing
- 5) Clean surface where Tube will be mounted - suggest using 3M Adhesive promoter, allow 5 minutes to dry
- 6) Heat Tube with heat gun or hair dryer for 5-10 seconds or until flexible. Be very careful not to bend tube side to side as board will snap.
- 7) Place Tube in desired location, bring open ends together, hold in place for 30 seconds
- 8) Apply another coat of silicon sealer over open ends.
- 9) Connect black wire to ground, Connect Red wire to appropriate turn signal
- 10) Repeat for other side

This product is not DOT Approved, for off road or show use only.

Disclaimer: Custom Dynamics LLC assumes no liability of any kind as a result of conversions or additions to your vehicle.