

# Street Magic® Cycle Products

## Signal Stabilizer™ XL Installation Instructions

**Fits: All 2004 to Present Harley-Davidson XL models**

1. Locate stock connector block for taillight/turn signals under seat.
2. Unplug main harness connector from fender harness connector.
3. Plug Signal Stabilizer™ in between these two connectors.
4. Test signals for proper operation. Test Alarm for proper operation, if equipped.

