



Custom Dynamics® TruFLEX® Integrated Plate Frame Installation Instructions

We thank you for purchasing the Custom Dynamics® TruFLEX® Integrated Plate Frame! Our products utilize the latest technology and high quality components to ensure you the brightest, most reliable LED's on the market. We offer one of the best warranty programs in the industry and we back our products with excellent customer support, if you have questions before or during installation of this product please call Custom Dynamics® at 1(800) 382-1388.

**Part Number: TF06-BCM-B
TF06-BCM-C**

Package Contents:

- License Plate Frame W/Mounting Screws (1)
- BCM Y Harness Adapter (1)
- 4" Tie Wraps (4)

Fits: 2014-2021 Harley-Davidson® Street Glide® (FLHX), Street Glide® Special (FLHXS), Street Glide® CVO™ (FLHXSE), Road Glide® (FLTRX), Road Glide® CVO™ (FLTRXSE), Road Glide® Special (FLTRXS), Road Glide® Ultra (FLTRU), Road Glide® Limited (FLTRK), Road Glide® Ultra CVO™ (FLTRUSE), Ultra Classic® (FLHTCU), Ultra Classic® Low (FLHTCUL), Ultra Limited (FLHTK), Ultra Limited Low (FLHTKL), Ultra Limited CVO™ (FLHTKSE), Road King® (FLHR), Road King® CVO™ (FLTRXSE), Road King® Special (FLHRS) and 2019-2021 Electra Glide® Standard (FLHT).

NOTE: Confirm license plate mounting bracket before purchasing. OEM mounting bracket may need to be modified or changed for radius license plate frame to mount properly. Plate frame requires 12 degree curved mounting.



ATTENTION



Please read all Information below before installation

Warning: Disconnect negative battery cable from battery; refer to owner's manual. Failure to do so may result in electrical shock, injury, or fire. Secure negative battery cable away from positive side of battery and all other positive voltage sources on vehicle.

Safety First: Always wear appropriate safety gear including safety glasses when performing any electrical work. It is highly recommended that safety glasses be worn throughout this installation process. Be sure vehicle is on level surface, secure and cool.

Important: This product is designed and intended for use as auxiliary lighting only. It is NOT intended to replace any original equipment lighting installed on the vehicle and should not be used for that purpose. This product must be wired so that it does not interfere with any original equipment lighting.



Installation:

1. Secure motorcycle on level surface. Remove seat. Disconnect negative battery cable from the battery.
 2. Locate and unplug the lighting connector to the rear fender.
 3. Plug the provided BCM Y Harness Adapter, in-line, into the rear lighting harness and into the bike's main wiring harness.
 4. Mount the license plate frame in the desired location with the provided hardware.
 5. Route the License Plate frame harness to the BCM Y Harness. Secure the harness from becoming cut, frayed, or pinched.
 6. Connect the License Plate frame harness to the BCM Y Harness.
 7. Reconnect the negative battery cable to the battery.
 8. Perform a BCM sync by turning the ignition on, turn the 4 way hazards on, turn the ignition off. Allow the 4 way hazards to run for 3-4 minutes. Turn the ignition on. Turn the 4 way hazards off. Turn the ignition off.
 9. Reinstall motorcycle seat and test all lighting for proper operation for run, brake and turn before riding.
- Functions **Run/Brake/Turn** on US Model 2014-2021 Street Glide®, Street Glide® Special, Road Glide®, Road Glide® Special, Road King® Special, Electra Glide® Ultra Classic®, Ultra Classic® Lo, Ultra Limited, Ultra Limited Lo, Road Glide® Ultra, Road Glide® Limited, 2016 Road Glide® Ultra CVO™ and 2016-2021 Limited CVO™.
 - Functions as **Run/Turn** on 2014-2018 Electra Glide® Police, 2014-2021 Road King®, 2014-2021 Street Glide® CVO™, 2018-2021 Road Glide® CVO™, 2014 Road King® CVO™, 2015 Road Glide® Ultra CVO™, 2014-2015 Ultra Limited CVO™ and 2019-2021 Electra Glide® Standard.

Questions? Call us at: 1 (800) 382-1388 M-TH 8:30AM-5:30PM / FR 9:30AM-5:30PM EST