



## Custom Dynamics® Magical Wizards™ Accent Light Kit Installation Instructions

We thank you for purchasing the Custom Dynamics® Magical Wizards™ Accent Light Kit. Our products utilize the latest technology and high quality components to ensure you the most reliable service. We offer one of the best warranty programs in the industry and we back our products with excellent customer support, if you have questions before or during installation of this product please call Custom Dynamics® at 1(800) 382-1388.

**Part Numbers:** TMWK1PG

### **Package Contents:**

- ProGLOW™ Bluetooth Controller (1)
- Magical Wizards™ 15 LED Strip (2)
- Magical Wizards™ 6 LED Strip (4)
- 4" Wire Tie (10)
- 1/2" 3M Tape (12")
- Mounting Stick (2)
- 3 Position Cage Clamp (4)



**Fits:** Compatible with 12vdc systems with a negative ground

### **Installation:**

1. Install the ProGLOW™ Bluetooth Controller. Refer to the instructions with the controller for installation.
2. Select hidden locations to mount LED strips to provide the best coverage of your choice. When selecting mounting locations, keep in mind the wire routing to either the controller or to the next LED strip.
3. Clean the selected locations with denatured alcohol and allow to dry.
4. When ready, remove the red backing from the LED strips and apply to the selected surfaces. Press lightly on each unit along the total surface of the LED for 10 seconds to ensure proper contact.
5. Route the LED strip harnesses to the controller.
6. Connect all LED strips to the zone output of the controller.
7. Secure the wires to the frame using the provided tie-wraps. Make sure the wiring is clear of any moving parts and does not interfere with normal operation.



Please read all Information below before Installation

**Warning:** Disconnect negative battery cable from battery; refer to owner's manual. Failure to do so may result in electrical shock, injury, or fire. Secure negative battery cable away from positive side of battery and all other positive voltage sources on vehicle.

**Safety First:** Always wear appropriate safety gear including safety glasses when performing any electrical work. It is highly recommended that safety glasses be worn throughout this installation process. Be sure vehicle is on level surface, secure and cool.

**Important:** This product is designed and intended for use as auxiliary lighting only. It is NOT intended to replace any original equipment lighting installed on the vehicle and should not be used for that purpose. This product must be wired so that it does not interfere with any original equipment lighting.

**Important:** Ambient install temperature must be 60 degrees F or higher. Allow 24 hours for tape to cure before washing or prolonged use of vehicle.

Questions? Call us at: 1 (800) 382-1388 M-TH 8:30AM-5:30PM / FR 9:30AM-5:30PM EST