



Custom Dynamics®
Rear Fender Adapter Harness

We thank you for purchasing the Custom Dynamics® Rear Fender Adapter Harness! Our products utilize the latest technology and high quality components to ensure you the most reliable service. We offer one of the best warranty programs in the industry and we back our products with excellent customer support, if you have questions before or during installation of this product please call Custom Dynamics® at 1(800) 382-1388.

Part Number: CD-HARN-F-BCM CD-HARN-F-SS6

Fitment: 1997-2013 Harley-Davidson® Electra Glide, Ultra Classic, Ultra Limited models (including CVO™), Road King (FLHR), Road King Classic (FLHRC), Road Glide Ultra (FLTRU) and Road Glide Ultra CVO™ (FLTRUSE), 1997-2009 Road Glide Standard (FLTR), and 2006-2009 Street Glide (FLHX) with 2010-2013 Street Glide (FLHX) or Road Glide Custom (FLTRX) rear fender conversion.



Installation:

1. Connect the 8pin connector to the OEM factory wiring harness under the seat.
2. Connect the 6pin connector to OEM rear fender lighting harness
3. Test all lighting for proper operation.

Questions? Call us at: 1 (800) 382-1388 M-TH 8:30AM-5:30PM / FR 9:30AM-5:30PM EST



Custom Dynamics®
Rear Fender Adapter Harness

We thank you for purchasing the Custom Dynamics® Rear Fender Adapter Harness! Our products utilize the latest technology and high quality components to ensure you the most reliable service. We offer one of the best warranty programs in the industry and we back our products with excellent customer support, if you have questions before or during installation of this product please call Custom Dynamics® at 1(800) 382-1388.

Part Number: CD-HARN-F-BCM CD-HARN-F-SS6

Fitment: 1997-2013 Harley-Davidson® Electra Glide, Ultra Classic, Ultra Limited models (including CVO™), Road King (FLHR), Road King Classic (FLHRC), Road Glide Ultra (FLTRU) and Road Glide Ultra CVO™ (FLTRUSE), 1997-2009 Road Glide Standard (FLTR), and 2006-2009 Street Glide (FLHX) with 2010-2013 Street Glide (FLHX) or Road Glide Custom (FLTRX) rear fender conversion.



Installation:

1. Connect the 8pin connector to the OEM factory wiring harness under the seat.
2. Connect the 6pin connector to OEM rear fender lighting harness
3. Test all lighting for proper operation.

Questions? Call us at: 1 (800) 382-1388 M-TH 8:30AM-5:30PM / FR 9:30AM-5:30PM EST