



Custom Dynamics® SXS Turn Signal Kit Installation Instructions

We thank you for purchasing the Custom Dynamics® SXS Turn Signal Kit Instructions. Our products utilize the latest technology and high quality components to ensure you the most reliable service. We offer one of the best warranty programs in the industry and we back our products with excellent customer support, if you have questions before or during installation of this product please call Custom Dynamics® at 1(800) 382-1388.

Part Number: CD-SXS-RZRTRAIL

US Patent D993198

Package Contents:

- CD-SXS-FTS-AW (1)
- SXS-TS-SW-1 (1)
- CD-ATC-6 (1)
- GEN-SMART-TPU-RZRTRAIL (1)

Fits: 2015-2020 Polaris RZR S 900, RZR S 900 Premium, 2015-2019 RZR 900, 2018 RZR S4 900, 2015-2017 RZR 4 900, RZR XP 1000, RZR XP 1000 High Lifter, 2016-2020 RZR S 1000, 2015-2018 RZR XP 4 1000, XP 4 1000 High Lifter, 2016-2018 RZR XP Turbo & RZR XP 4 Turbo models.

Note: Not compatible with vehicles equipped with OE Ride Command



ATTENTION

Please read before Installation

Warning: Disconnect negative battery cable from battery; refer to owner's manual. Failure to do so may result in electrical shock, injury, or fire. Secure negative battery cable away from positive side of battery and all other positive voltage sources on vehicle.

Safety First: Always wear appropriate safety gear including safety glasses when performing any electrical work. It is highly recommended that safety glasses be worn throughout this installation process. Be sure vehicle is on level surface, secure and cool.

Note: Please refer to each individual set of included Instructions for specific notes and warnings for each part. Always refer to your manufacturers service manual if unsure of any procedure.

Important: It is recommended that the installation of this product should be performed in a controlled environment with constant temperature of 70F or above to allow proper adhesion. Allow 24 hours before riding or washing the bike.

Installation:

1. Disconnect battery negative cable. Refer to Owners manual if unsure of the process.
2. Install the CD-ATC-6. Follow the procedure in the included instructions with the CD-ATC-6 for specifics on installation and wiring connections.
3. Install the SXS-TS-SW-1. Follow the procedure in the included instructions with the SXS-TS-SW-1 for specifics on installation and wiring connections.
4. Install the GEN-SMART-RZRTRAIL Follow the procedure in the included instructions with the GEN-SMART-RZRTRAIL for specifics on installation, wiring connections and programming.
5. Install the CD-SXS-FTS-AW. Follow the procedure in the included instructions with the CD-SXS-FTS-AW for specifics on installation, mounting and wiring connections
6. Reinstall battery negative cable and test all lighting for proper operation before operating the vehicle.

Questions? Call us at: 1 (800) 382-1388 M-TH 8:30AM-5:30PM / FR 9:30AM-5:30PM EST