



Custom Dynamics® H4 Tour Adapter Harness Installation Instructions


We thank you for purchasing the Custom Dynamics® LED Headlamp Adapter Harness! Our products utilize the latest technology and high quality components to ensure you the most reliable service. We offer one of the best warranty programs in the industry and we back our products with excellent customer support, if you have questions before or during installation of this product please call Custom Dynamics® at 1(800) 382-1388.

Part Number: H4-TOUR-ADPT

Package Contents:

- Adapter Harness (1)

Fits: 2014-2020 Harley Davidson® Street Glide®, Electra Glide® and TriGlide® Models.



Note: These instructions reference the use of a Service Manual. A manual is required for this installation. Please contact the manufacturer to obtain a service

Removal

1. Remove the headlamp. If you are not familiar with this process, please refer to the instructions in the service manual for your bike.
2. Disconnect the OEM headlamp harness from the main harness. Discard.

Installation—Fairing Models

1. Connect the LED adapter harness to the main harness connector.
2. Connect the Headlamp to the H4 Socket.

Note: The Blue wire with spade not connected to the H4 Connector is not used in all cases, it is for the position light on some headlamps.

3. Follow the instructions included with the new LED headlamp and finish installation.
4. Test operation of both high and low beam functions.

Questions? Call us at: 1 (800) 382-1388 M-TH 8:30AM-5:30PM / FR 9:30AM-5:30PM EST