



## Custom Dynamics® Spyder® Stingerz® Installation Instructions

We thank you for purchasing the Custom Dynamics® Stingerz®! Our products utilize the latest technology and high quality components to ensure you the most reliable service. We offer one of the best warranty programs in the industry and we back our products with excellent customer support, if you have questions before or during installation of this product please call Custom Dynamics® at 1(800) 382-1388.

### Part Numbers: ST5

#### Package Contents:

- Stingerz® 99 LED Strip (1)
- Stingerz® 69 LED Strip (2)
- Stingerz® 30 LED Strip (7)
- Stingerz® 24 LED Strip (3)
- Stingerz® 12 LED Strip (9)
- Stingerz® 9 LED Strip (2)
- 5 oz. Mini Goop Tube (1)
- Heat Shrink insulated terminals (2)
- Blue Butt Connector (2)
- Adhesive Primer (5)
- 3M Tape 1" (1)
- 4" Black Tie Wraps (30)
- 22 Gauge Conductor Cable (40')
- Adhesive Lined Heat Shrink (4')
- 5 Cage Clamp® connectors (2)
- 2 Cage Clamp® connectors (16)
- 3 Cage Clamp® connectors (4)
- Weather Proof Fuse Holder w/ 3amp Mini Fuse (1)
- Red/ Black wire, 18 AWG (1')
- Weather Proof Push Button Switch with Boot (1)

Fits: 2008-2017 Can Am Spyder RS, RS-S, 2013-2016 ST, STS; compatible with 12VDC systems with a negative ground.

Compatible with: Black Magic™ 4 Remote, Magic™ Zone Remote or Simple On/Off remote.

### Tools Needed:

- Screwdriver (flat and Philips)
- Wire Cutter/stripper
- Wire Crimpers
- Heat Gun
- Open end wrenches
- Razor blade cutting tool

Note: This product is designed and intended for use as auxiliary lighting only. It is NOT intended to replace any original equipment lighting installed on the vehicle and should not be used for that purpose. This product must be wired so that it does not interfere with any original equipment lighting.

### Installation:

1. Always wear appropriate safety gear including safety glasses when soldering or performing any electrical work. It is highly recommended that safety glasses be worn throughout this installation process. Temperature of bike must be at least 60 degrees F. for tape to properly cure. Read all directions before starting project.
2. Turn fuel supply valve to off position before starting. Be sure bike is on level surface and secure and cool.
3. **Important:** Disconnect negative battery cable from battery; refer to owner's manual. Failure to do so may result in electrical shock, injury, or fire. Secure negative battery cable away from positive side of battery and all other positive voltage sources on bike.
4. Select hidden locations to mount Stingerz® to provide best coverage. (See attached pictures for Can Am Spyder)
5. Clean mounting locations on motorcycle with alcohol, apply adhesive primer and allow to dry.
6. Select appropriate mounting location for push button switch. Place 3M tape on switch and mount switch on bike, place waterproof boot on switch.
7. Join all black wires from LEDs to piece of 18 AWG black wire using the supplied Cage Clamp Connector.

Questions? Call us at: 1 (800) 382-1388 M-TH 8:30AM-5:30PM / FR 9:30AM-5:30PM EST

## Installation Instructions - Page 2

### Installation-Continued

- 8) Take remaining end of 18 AWG black wire and route to frame ground on bike. Use terminal connector to connect to frame ground or negative side of battery, insert wire and crimp.
- 9) Join all red wires from LEDs to remaining Cage Clamp Connector. Connect one end of Red 18AWG into Cage Clamp Connector.
- 10) Connect one end of push button switch to 18 AWG Red with Blue butt connector. Crimp wires in butt connector..
- 11) Connect remaining end of push button switch to one end of fuse holder with a blue butt connector, insert wire and crimp.
- 12) Place remaining terminal connector on remaining wire of Fuse holder. Crimp wire in terminal connector.
- 13) Connect end of Fuse holder with spade terminal to Positive (+) side of battery. Take necessary precautions when making connection and refer to bike's owner's manual. DO NOT allow any tools to touch both positive (+) side of battery and any metal surface on bike as it will cause a short which could result in serious injury and damage to the battery or other electrical circuits.
- 14) Secure any remaining wires with tie wraps.
- 15) Heat the heat shrinkable connectors with heat gun or blow dryer until it shrinks down around wires.
- 16) Reconnect Negative Battery terminal to negative side of battery taking necessary precautions not to touch positive side of battery or any positive cable.
- 17) Place fuse in fuse holder and replace cover.
- 18) Turn on switch and check operation of all lights. Allow double-sided tape to bond for 72 hours before exposing to water

### Cage Clamp® Instructions



Strip wire 9-10 mm. Use the stripped wire gauge on the back of the connector to verify correct strip length.



Push up lever and insert conductor



Push down lever to its closed position.



## Installation Instructions - Page 3



## Installation Instructions - Page 4





## Installation Instructions - Page 5



## Installation Instructions - Page 6





## Installation Instructions - Page 7

