

Helpful photos to guide you in the correct mounting of your tour bag



1. Attach the RickRak to your tour pak luggage rack



2. Place and center your tour bag onto the RickRak



3. Mark the rear corners of your tour bag to indicate where it will be mounted on RickRak



4. Take the tour bag and place upside down with some wood under it so it can be punched, and place the RickRak upside down on it.



5. Place RickRak on the bag lined up with the marks, then mark the holes you will need.



6. Now with holes marked, remove RickRak and punch the holes

Using a silver colored sharpie will work best for marking the tour bag and holes.

If possible use a hollow 1/4" hole punch for making the holes, this works best.

Be sure when mounting the RickRak, that the clamps are on the right side of the bike over the tourpak latch



Once your tour bag is properly mounted, the inside should look like the photo on the left and the underneath will look like the photo on the right.

Instructions for attaching your tour bag to the RickRak Quick Attach



We have supplied 6 sets of bolts and washers, smaller bags may only require the use of 4 sets.

After deciding on which holes in the RickRak Quick Attach are the best locations to use for your particular tour bag, mark and drill, pierce, or punch corresponding holes in your tour bag so it may be mounted.

Then using the drawing above as a guide place the bolt through the Steel Washer, Large rubber washer, Tour bag. Small rubber washer, and RickRak Quick Attach, then attach the Lock nut on the end.

Tighten, and repeat so that the tour bag is securely attached in four or six locations.

THE RECOMMENDED PROCEDURE TO MAKE THE HOLES IS A 1/4" HOLLOW PUNCH - SEE PHOTO BELOW



TOOLS NEEDED:

Hex wrench supplied, 7/16" socket or wrench, and a 1/4" drill, punch or awl to pierce holes
**BECAUSE ALL NUTS AND BOLTS ARE STAINLESS STEEL YOU MUST USE ANTI-SEIZE ON THE THREADS
FOR YOUR CONVENIENCE WE HAVE INCLUDED THE ANTI SIEZE YOU WILL NEED FOR THE BOLTS**

USING THE RICKRAK QUICK ATTACH

After attaching your tour bag to the RickRak Quick Attach, in 10 seconds or less, your tour bag can be securely attached to the luggage rack !!!

- Step 1** Place the notched end of the RickRak over the the left side rail of the luggage rack, leave about ¼ inch from the bar to the back side of the notch... as you tighten the clamps, the rack will become tight on the luggage rack



Slip notched end over left bar

Leave ¼ inch gap



- Step 2** With the notched end in place, lower the clamped end down to the right side rail of the luggage rack, no force is necessary if the clamps are properly opened. Once in place, simply tighten the clamps, and you are now ready to ride.

CAUTION DO NOT OVER TIGHTEN !!! CLAMPS NEED ONLY BE SNUGGED



Bring clamps down to bar

Tighten Clamps



When clamps tighten, notch will tighten also



- Step 3** When your ride is done and it's time to settle in, removing the tour pak with the RickRak is only another 10 seconds. Just loosen the clamps and lift the RickRak off. Hint: After loosening the clamps, slide the RickRak slightly towards the clamps, then lift. Ride Safe



To remove open clamp

Slide rack slightly to right



Now you can lift and remove your tour pak

NO STRAPS QUICK AND SECURE
ADAPTABLE TO HUNDREDS OF TOUR BAGS
REMEMBER: DO NOT OVER TIGHTEN CLAMPS

CLAMP POSITIONING FOR CORRECT RACK

THIS RICKRAK CAN BE USED ON EITHER OF THE TWO

MOST POPULAR HARLEY DAVIDSON LUGGAGE RACKS

IF YOUR RICKRAK WAS SHIPPED IN THE HOLE NOT DESIGNED

FOR YOUR LUGGAGE RACK, YOU CAN SIMPLY CHANGE IT TO

FIT YOUR LUGGAGE RACK. USING THE HEX WRENCH INCLUDED

IN THE PACKAGE, MOVE THE CLAMP FROM THE CURRENT HOLE

IT IS CURRENTLY LOCATED, AND MOVE IT TO THE HOLE

THAT IS ADJACENT TO IT. ONCE MOVED, IT WILL FIT YOUR RACK

SEE BELOW DRAWING SHOWING WHICH HOLE YOUR RACK REQUIRES.



mount clamp in desired hole to fit original or air-wing design