



Custom Dynamics® Quick Disconnect Tour-Pak Wiring Harness Installation Instructions

We thank you for purchasing the Custom Dynamics® Quick Disconnect Tour-Pak Wiring Harness! Our products utilize the latest technology and high quality components to ensure you the most reliable service. We offer one of the best warranty programs in the industry and we back our products with excellent customer support, if you have questions before or during installation of this product please call Custom Dynamics® at 1(800) 382-1388.

Part Number: CD-TP-QD-13

Package Contents:

- Quick Disconnect Tour-Pak Wiring Harness (1)
- Instructions (1)

Fitment: 1997-2013 Harley-Davidson® Electra Glide® Ultra Classic/Limited Models, 2011-2013 Road Glide® Ultra & 2008-2013 Tri Glide® Models with King & Ultra Tour Pak®

Does not fit OEM LED Tour-Pak® on CVO™ models.



ATTENTION

Please read all Information below before Installation

Warning: Disconnect negative battery cable from battery; refer to owner's manual. Failure do to so may result in electrical shock, injury, or fire. Secure negative battery cable away from positive side of battery and all other positive voltage sources on vehicle.

Important: Motorcycle should be secured on a level surface for installation.

Important: This product is designed to be used specifically with the Harley-Davidson® brand Tour-Pak wiring harness.

Installation:

1. Secure motorcycle on level surface. Remove seat. Disconnect negative battery cable from the battery.
2. Locate and unplug the rear lighting harness connector to the rear fender from the main wiring harness.
3. Plug the Quick Disconnect Tour-Pak Wiring Harness, in-line, into the rear lighting harness and into the bike's main wiring harness.
4. Re-connect the battery's negative battery cable to the negative of the battery.
5. Route the Quick Disconnect Tour-Pak Wiring Harness towards the seat bolt on the rear fender.
6. Reinstall the seat and ensure the Quick Disconnect Tour-Pak Wiring Harness will not be pinched or damaged under the seat when installed.
7. Install your Tour-Pak and connect the Tour-Pak wiring harness to the Quick Disconnect Tour-Pak Wiring Harness.
8. Check operation of all lighting before riding.

Questions? Call us at: 1 (800) 382-1388 M-TH 8:30AM-5:30PM / FR 9:30AM-5:30PM EST