



Custom Dynamics® Genesis® 4 LED

Turn Signal Installation Instructions

We thank you for purchasing the Custom Dynamics® Genesis® 4 LED Turn Signals. Our products utilize the latest technology and high quality components to ensure you the most reliable service. We offer one of the best warranty programs in the industry and we back our products with excellent customer support, if you have questions before or during installation of this product please call Custom Dynamics® at 1(800) 382-1388.

Part Numbers: GEN-4-RR-1157

Package Contents:

- Genesis 4 Red Ring LED Clusters (1 pair)

Fits: Red Ring turn signals on Harley-Davidson® US Models with 1157 dual contact bases and Bullet Style (Pop-off) lens. Does not fit 2016 - 2020 CVO™ Models



Please read all Information below before Installation

Warning: Disconnect negative battery cable from battery; refer to owner's manual. Failure to do so may result in electrical shock, injury, or fire. Secure negative battery cable away from positive side of battery and all other positive voltage sources on vehicle.

Safety First: Always wear appropriate safety gear including safety glasses when performing any electrical work. It is highly recommended that safety glasses be worn throughout this installation process. Be sure vehicle is on level surface, secure and cool.

NOTE: DOT Compliant when used behind Custom Dynamics® smoked or red motorcycle turn signal lens (sold separately).

NOTE: This product is designed for dual intensity rear turn signal fitment only. They will not function properly in the front. For proper color output, use a smoked or red lens.

Important Tips and Troubleshooting:

1. Dielectric grease does not need to be used with this LED product, it can actually prevent them from working.
2. Make sure you have the base orientation correct before inserting the base. If it seems hard to twist in the socket, it's probably in the wrong way.
3. Harley Davidson® Bullet turn signals may require trimming of black gasket to fully seat lens.
4. If you experience issues with function, clean the bottom contacts, then re-insert. Also, try in the other turn signal socket.
5. If you experience fast flashing from your turn signals after installation, you may need a load equalizer or our Smart Signal Stabilizer™. Contact us for details.
6. This LED Product is BCM Compliant. If installing on 2011 and newer Softails®, 2012 and newer Dynas®, or any 2014 & newer model Harley Davidson®, it is recommended to run the 4 way hazards for 5 minutes to re-sync the CanBus system. No load equalizer or Smart Signal Stabilizer™ is needed for these models.

Installation:

1. Remove lens from turn signal housing.
2. Remove bulb from turn signal housing.
3. Remove any corrosion or dielectric grease from the socket contacts.
4. Confirm the proper orientation of the socket base and insert the base into the socket. If it seems hard to twist the base in the socket or hard to remove, it is probably orientated the wrong way.
5. Twist the LED turn signal a few rotations to coil wire from the turn signal to the socket base. Insert LED turn signal into housing and install new lens.
6. Check operation of turn signal in all modes.

Questions? Call us at: 1 (800) 382-1388 M-TH 8:30AM-5:30PM / FR 9:30AM-5:30PM EST