



Custom Dynamics® Road King Dynamic Strip Adapter Installation Instructions

We thank you for purchasing the Custom Dynamics® Road King Dynamic Strip Adapter. Our products utilize the latest technology and high quality components to ensure you the most reliable service. We offer one of the best warranty programs in the industry and we back our products with excellent customer support, if you have questions before or during installation of this product please call Custom Dynamics® at 1(800) 382-1388.

Part Numbers: DS-HAR-RK-13-JAE

Package Contents:

- Road King Dynamic Strip Adapter (1)



Fits: 1996-2013 Road King models when installing with PB-DS-14 (Not Included)

Installation:

1. Locate the front Left and Right Turn Signal Connector in the Headlight Nacelle, on the left side fork stem nut lock plate.
2. Disconnect the Left and Right OEM Turn Signal connector from the main harness.
3. Connect the Road King Dynamic Strip Adapter to the main wiring harnesses.
4. Connect the Dynamic Strip harnesses to the Road King Dynamic Strip Adapter JAE connectors. The JAE connector with the Brown wire is for the right side. The JAE Connector with the Purple wire is for the Left side.
5. Test lighting in all modes for proper operation before riding.



Please read all Information below before Installation

Warning: Disconnect negative battery cable from battery; refer to owner's manual. Failure to do so may result in electrical shock, injury, or fire. Secure negative battery cable away from positive side of battery and all other positive voltage sources on vehicle.

Safety First: Always wear appropriate safety gear including safety glasses when performing any electrical work. It is highly recommended that safety glasses be worn throughout this installation process. Be sure vehicle is on level surface, secure and cool.

Questions? Call us at: 1 (800) 382-1388 M-TH 8:30AM-5:30PM / FR 9:30AM-5:30PM EST