



## Custom Dynamics® LED Backrest Bracket Installation Instructions

We thank you for purchasing the Custom Dynamics® LED Backrest Bracket for 2010-2013 Harley Davidson® Street Glide® and Road Glide® Custom Models. Our products utilize the latest technology and high quality components to ensure you the most reliable service. We offer one of the best warranty programs in the industry and we back our products with excellent customer support, if you have questions before or during installation of this product please call Custom Dynamics® at 1(800) 382-1388.

**Part Numbers:** CD-BR-SS6-B  
CD-BR-SS6-C

**Package Contents:**

- Backrest LED Assembly (1)
- Backrest Adapter Harness (1)
- 4" Black Tie Wraps (6)

**Fits:** Harley Davidson® 2010-2013 US Model Harley-Davidson® Street Glide® and Road Glide® Custom (Replaces OEM 52565-94)



### Installation:

1. Remove motorcycle seat, left saddlebag and left side cover. Consult your owners manual if unsure of this process.
2. Disconnect the negative [-] battery cable from the battery.
3. Locate the rear lighting harness connectors in left side cover compartment. Plug in the included Adapter Harness in-line between the male and female rear lighting harness connectors.
4. Loosen the screws securing the stock backrest bracket and remove. Save the screws for reinstallation.
5. Install the LED backrest assembly to the backrest securing the assembly with the original screws.
6. Route the LED Backrest quick disconnect wiring harness down the backrest towards the left side cover compartment and secure to the Backrest using the supplied tie wraps.
7. Connect the LED quick disconnect harness connector to the Backrest Adapter Harness.
8. Reconnect the negative battery cable to the negative of the battery.
9. Install the motorcycle seat, saddlebag and side cover.
10. Test operation of all lighting before riding.



Please read all Information below before Installation

**Warning:** Disconnect negative battery cable from battery; refer to owner's manual. Failure to do so may result in electrical shock, injury, or fire. Secure negative battery cable away from positive side of battery and all other positive voltage sources on vehicle.

**Safety First:** Always wear appropriate safety gear including safety glasses when performing any electrical work. It is highly recommended that safety glasses be worn throughout this installation process. Be sure vehicle is on level surface, secure and cool.

**Important:** This product is designed and intended for use as auxiliary lighting only. It is NOT intended to replace any original equipment lighting installed on the vehicle and should not be used for that purpose. This product must be wired so that it does not interfere with any original equipment lighting.

Questions? Call us at: 1 (800) 382-1388 M-TH 8:30AM-5:30PM / FR 9:30AM-5:30PM EST