



Custom Dynamics® Low Profile Sequential Saddlebag LED Lights Installation Instructions

We thank you for purchasing the Custom Dynamics® Low Profile Sequential Saddlebag LED Lights. Our products utilize the latest technology and high quality components to ensure you the most reliable service. We offer one of the best warranty programs in the industry and we back our products with excellent customer support, if you have questions before or during installation of this product, please call Custom Dynamics® at 1(800) 382-1388.

Part Numbers: CD-LPSEQ-SS8-R CD-LPSEQ-SS8-S
CD-LPSEQ-SS8-DC-R CD-LPSEQ-SS8-DC-S

Package Contents:

- Saddlebag LED Light W/ Quick Disconnect Harness (2)
- SS8 Adapter Harness (1)
- 4" Cable Tie (10)
- Tie Wrap Holder (6)



Fits: Harley-Davidson® 2009 Road Glide CVO™, 2010-2012 Street Glide CVO™, 2012-2013 Road Glide® Custom CVO™ and 2013 Road King CVO™ with H-D™ OEM hard saddlebags.

Installation:

1. Remove the seat and disconnect the negative battery cable from the battery.
2. Locate the rear main lighting harness to the rear fender. Unplug and install the SS8 Adapter Harness in line with the rear fender lighting.

Note: The order of installation will be bike's SS8 main wiring harness, Smart Signal Stabilizer™/Load Equalizer (if installed), brake strobe module (if installed), SS8 Adapter Harness, Run/Brake/Turn module (if installed) and then the bike's rear lighting harness.

3. Test fit the Low Profile Sequential Saddlebag Lights. The saddlebag light with the purple wire in the harness will mount on the left saddlebag. The saddlebag light with the brown wire in the harness will mount on the right saddlebag. The light should mount a couple millimeters below the bottom edge of the lid when the lid is closed. Mark the location with a grease pencil.
4. Clean area with the provided denatured alcohol, allow to dry.
5. Remove the red adhesive backing and install the lights on the left and right saddlebags. Press into place making sure the adhesive tape is making contact with the saddle bag.
Note: Do not apply too much pressure in the center of the Low Profile BAGZ™ Saddle Bag Lights. This can cause the lens to crack and will not be covered under warranty.
6. Remove both bags from the bike.
7. Select location for cable tie holders. Clean area with denatured alcohol, allow to dry. Remove paper backing for cable tie holders and press into place. Refer to Picture 1.



ATTENTION



Disclaimer: Removal of our saddlebag lights after installation, may cause permanent damage to the finished surface area of the saddlebag.

Warning: Disconnect negative battery cable from battery; refer to owner's manual. Failure to do so may result in electrical shock, injury or fire. Secure negative battery cable away from positive side of battery and all other positive voltage sources on vehicle.

Safety First: Always wear appropriate safety gear including safety glasses when performing any electrical work. It is highly recommended that safety glasses be worn throughout this installation process. Be sure vehicle is on level surface, secure and cool.

Important: This product is designed and intended for use as auxiliary lighting only. It is NOT intended to replace any original lighting installed on the vehicle and should not be used for that purpose.

Installation Instructions - Page 2

Installation Continued:

8. Route wires from bag light to each tie wrap holder location and secure with enclosed tie wraps.
9. Reinstall saddlebags. Connect the black 4 pin JAE connector from bag lights to the SS8 Adapter Harness.
10. Secure wires under the seat with the included cable ties. Make sure wiring will not come in contact with moving parts or in an area with high heat. Take care that wires will not get pinched or frayed when the seat is installed.
11. Reinstall motorcycle seat and test operation of all lighting for proper running, brake and turn before riding.

1



BAGZ™ come with plug and play weatherproof quick disconnect to make future removal of saddlebags quick and easy (see pictures below).

