



Custom Dynamics® Micro Turn Signal Adapter Installation Instructions

We thank you for purchasing the Custom Dynamics® Micro Turn Signal Adapter. Our products utilize the latest technology and high quality components to ensure you the most reliable service. We offer one of the best warranty programs in the industry and we back our products with excellent customer support, if you have questions before or during installation of this product please call Custom Dynamics® at 1(800) 382-1388.

Part Numbers: MPR-MICROAR-HD

Package Contents:

-HD Micro Turn Signal Adapter (1)

Fits: 1996-2017 Harley-Davidson® Softails® (except Breakout®, CVO™ Breakout/Pro Street, Rocker/Rocker C, Slim/Slim-S®, Blackline® or Softail® Convertible CVO™), 1997-2011 Dyna Models, 1999-2003 Sportster Models, 1997-2013 Harley-Davidson® Electra Glide, Ultra Classic, Ultra Limited models (including CVO™), Road King (FLHR), Road King Classic (FLHRC), Road Glide Ultra (FLTRU), Road Glide Ultra CVO™ (FLTRUSE), 1998-2009 Road Glide Standard (FLTR), 2006-2009 Street Glide (FLHX), 2010-2011 Street Glide Trike (FLHXXX) and 2010-2013 Tri Glide® Ultra Classic (FLHTCUTG).



ATTENTION

Please read all Information below before Installation

Warning: Disconnect negative battery cable from battery; refer to owner's manual. Failure to do so may result in electrical shock, injury, or fire. Secure negative battery cable away from positive side of battery and all other positive voltage sources on vehicle.

Safety First: Always wear appropriate safety gear including safety glasses when performing any electrical work. It is highly recommended that safety glasses be worn throughout this installation process. Be sure vehicle is on level surface, secure and cool.

Important: This product is designed and intended for use as auxiliary lighting only. It is NOT intended to replace any original equipment lighting installed on the vehicle and should not be used for that purpose. This product must be wired so that it does not interfere with any original equipment lighting.



Installation:

1. Secure motorcycle on level surface. Remove seat and disconnect negative battery cable from the battery.
2. Locate and unplug the rear lighting harness connector to the rear fender.
3. Plug the provided HD Micro Turn Signal Adapter, in-line, into the rear lighting harness and into the bike's main wiring harness.

Note: The order of installation, front to back, will be bike's HD main wiring harness, Smart Signal Stabilizer™/Load Equalizer (if installed), brake strobe module (if installed), HD Micro Turn Signal Adapter, Run/Brake/Turn module (if installed) and then the bike's rear lighting harness.

4. Connect the Micro Turn Signals (Sold Separately) to the installed HD Micro Turn Signal Adapter. Connect Left Micro Turn Signal to the 4 pin connector of the Adapter with the Purple wire. Connect Right Micro Turn Signal to the 4 pin connector of the Adapter with the Brown wire.
5. Secure wires to prevent the wires from becoming cut, frayed, or pinched.
6. Reconnect the negative battery cable to the battery and reinstall the seat.
7. Test operation of all lighting before riding.

Questions? Call us at: 1 (800) 382-1388 M-TH 8:30AM-5:30PM / FR 9:30AM-5:30PM EST