



Custom Dynamics® ProBEAM®  
Indian Scout Replacement Lenses  
Installation Instructions

We thank you for purchasing the Custom Dynamics® ProBEAM® Indian Scout Replacement Lenses! Our Lenses offer maintenance free service and higher visibility. Our ProBEAM® product line utilizes the latest technology and automotive grade components to ensure the highest level of reliable service. Custom Dynamics® offers one of the best warranty programs and customer support in the industry. If you have any questions during the installation of this product please call us at 1(800) 382-1388.

**Part Numbers:**

PB-SCOUT-AMBER PB-SCOUT-RED PB-SCOUT-SMOKE

**Package Contents:**

- ProBEAM® PB-SCOUT-LENS (2)
- Instructions

**Fitment:** 2015-2021 Indian Scout & Scout Sixty (Does NOT fit Scout Bobber models)



**ATTENTION**

Please read all Information below before Installation

**Warning:** Disconnect negative battery cable from battery; refer to owner's manual. Failure to do so may result in electrical shock, injury, or fire. Secure negative battery cable away from positive side of battery and all other positive voltage sources on vehicle.

**Safety First:** Always wear appropriate safety gear including safety glasses when performing any electrical work. It is highly recommended that safety glasses be worn throughout this installation process. Be sure vehicle is on level surface, secure and cool.

**Installation:**

1. Locate the 2 Phillips screws in the face of the turn signal.
2. Hold the lens as you remove the 2 Phillips screws (keep the screws you will need them to install the new lens).
3. Clean any dirt or grime from housing.
4. Installing the lens on the housing, make sure the rubber gasket sits flush to the housing.
5. Reinstall the 2 existing Phillips head screws. Overtightening the lens will cause the lens to crack.

Questions? Call us at: 1 (800) 382-1388 M-TH 8:30AM-5:30PM / FR 9:30AM-5:30PM EST