



Custom Dynamics® ProBEAM® LED Halo Fog Lamps
Installation Instructions

We thank you for purchasing the Custom Dynamics® ProBEAM® LED Halo Fog Lamps. Our products utilize the latest technology and high quality components to ensure you the most reliable service. We offer one of the best warranty programs in the industry and we back our products with excellent customer support, if you have questions before or during installation of this product please call Custom Dynamics® at 1(800) 382-1388.

Part Number: PB-FOG-BCM-B, PB-FOG-BCM-C

- Package Contents:**
- ProBEAM® LED Halo Fog Lamp (2)
 - Wiring Harness
 - Chrome Wire Tie (10)
 - Black Wire Tie (10)
 - Isopropyl Alcohol Wipe
 - Instructions



Fits: 2014-2021 Harley-Davidson® Street Glide (FLHX), Street Glide Special (FLHXS), Street Glide CVO (FLHXSE), Road Glide (FLTRX), Road Glide CVO (FLTRXSE), Road Glide Special (FLTRXS), Road Glide Limited (FLTRK), Road Glide Ultra (FLTRU), Road Glide Ultra CVO (FLTRUSE), Electra Glide Standard (FLHT), Ultra Classic (FLHTCU), Ultra Classic Low (FLHTCUL), Ultra Limited (FLHTK), Ultra Limited Low (FLHTKL), Ultra Limited CVO (FLHTKSE), Road King (FLHR), Road King CVO (FLTRXSE), and Road King Special (FLHRS).

- Installation:**
1. Remove the seat and disconnect the motorcycle's negative (-) battery cable from the battery.
 2. Determine desired place to mount the driving lights. For optimal performance, it is recommended the fog lamps be mounted horizontally on the outermost section of the engine guard by means of a mounting clamp (not included). Refer to Photo 1.
 3. Install the ProBEAM® LED Halo Fog Lamp mounting stud into the clamp and secure to the mounting clamp as shown in Photo 1.

ATTENTION

Please read all Information below before Installation

CAUTION: Unit is HOT when operating, DO NOT TOUCH.

Warning: To prevent possible electrical shock, disconnect the negative Battery terminal before installing this product.

Important: This product is designed and intended for use as auxiliary lighting only. It is NOT intended to replace any original equipment lighting installed on the vehicle and should not be used for that purpose. This product must be wired so that it does not interfere with any original equipment lighting.

Note: Mounting studs are 5/16" in diameter, please verify your mounting clamp hole before installation.

Note: Fog lamps are setup to be mounted in a horizontal position. For vertical mounting (perpendicular to the ground) the optics will need to be rotated 90 degrees. To prevent damage to the unit, please refer to the video at <https://tinyurl.com/y27e5fdy> before attempting to rotate the optics. Refer to Photo 3 on Page 2 for mounting orientation.



4. Route wiring of the ProBEAM® LED Halo Fog Lamp under the seat. Use the provided wire ties to secure the wire to prevent damage. When routing the wire, add a drip loop to prevent water from running back into the Fog Lamp. Refer to Photo #2 on Page 2.

Questions? Call us at: 1 (800) 382-1388 M-TH 8:30AM-5:30PM / FR 9:30AM-5:30PM EST

