



Custom Dynamics® Quick Disconnect Tour-Pak Wiring Harness Installation Instructions

We thank you for purchasing the Custom Dynamics® Quick Disconnect Tour-Pak Wiring Harness! Our products utilize the latest technology and high quality components to ensure you the most reliable service. We offer one of the best warranty programs in the industry and we back our products with excellent customer support, if you have questions before or during installation of this product please call Custom Dynamics® at 1(800) 382-1388.

Part Number: CD-TP-QD-14

Package Contents:

- Quick Disconnect Tour-Pak Wiring Harness (1)
- Instructions (1)

Fitment: 2014-2024 Harley-Davidson® Ultra Limited (FLHTK), 2020-2024 Road Glide Limited (FLTRK), 2022-2023 CVO™ Road Glide Limited (FLTRKSE), 2014-2019 Electra Glide Ultra Classic (FLHTCU), 2015-2016 Ultra Classic Lo (FLHTCUL) & CVO™ Road Glide Ultra (FLTRUSE), 2016-2019 Road Glide Ultra (FLTRU), 2015-2018 Ultra Limited Lo (FLHTKL), 2014-2021 CVO™ Limited (FLHTKSE), 2014-2024 Tri Glide (FLHTCUTG) and 2020-2022 CVO™ Tri Glide (FLHTCUTGSE) with OEM King Tour Pak.

Also fits 2014-2023 Harley-Davidson® Street Glide (FLHX), Street Glide Special (FLHXS), 2015-2023 Road Glide (FLTRX), Road Glide Special (FLTRXS), 2017-2024 Road King Special (FLHRXS), 2014-2022 Road King (FLHR), 2022-2023 Street Glide ST (FLHXST), Road Glide ST (FLTRXST), 2015-2022 CVO™ Street Glide (FLHXSE), 2018-2022 CVO™ Road Glide (FLTRXSE), 2019-2022 Electra Glide Standard (FLHT) and 2014 CVO™ Road King (FLHRSE) with add-on King or Chopped style Tour Pak.



Please read all Information below before Installation

Warning: Disconnect negative battery cable from battery; refer to owner's manual. Failure to do so may result in electrical shock, injury, or fire. Secure negative battery cable away from positive side of battery and all other positive voltage sources on vehicle.

Important: Motorcycle should be secured on a level surface for installation.

Important: This product is designed to be used specifically with the Harley-Davidson® brand Tour-Pak wiring harness.



Installation:

1. Secure motorcycle on level surface. Remove seat. Disconnect negative battery cable from the battery.
2. Locate and unplug the rear lighting harness connector to the rear fender from the main wiring harness.
3. Plug the Quick Disconnect Tour-Pak Wiring Harness, in-line, into the rear lighting harness and into the bike's main wiring harness.
4. Re-connect the battery's negative battery cable to the negative of the battery.
5. Route the Quick Disconnect Tour-Pak Wiring Harness towards the seat bolt on the rear fender.
6. Reinstall the seat and ensure the Quick Disconnect Tour-Pak Wiring Harness will not be pinched or damaged under the seat when installed.
7. Install your Tour-Pak and connect the Tour-Pak wiring harness to the Quick Disconnect Tour-Pak Wiring Harness.
8. Check operation of all lighting before riding.

Questions? Email: info@CustomDynamics.com or Call us at: 1 (800) 382-1388 M-TH 8:30AM-5:30PM / FR 9:30AM-5:30PM EST