



Custom Dynamics® Flat Style H-D™ Turn Signal Lenses For Incandescent Bulbs

Installation Instructions

We thank you for purchasing the Custom Dynamics® Flat Style H-D™ Turn Signal Lenses For Incandescent Bulbs . Our products utilize the latest technology and high quality components to ensure you the most reliable service. We offer one of the best warranty programs in the industry and we back our products with excellent customer support. If you have questions before or during installation of this product, please call Custom Dynamics® at 1(800) 382-1388.

Part Number: HDFLATAMBER HDFLATRED
HDFLATCLEAR HDFLATSMOKE

Package Contents:

- HDFLAT LENS (1)

Fitment: 1986-2022 Harley-Davidson® Models with Flat (pancake) Style H-D™ Turn Signal Lenses with 2 screws.

Installation:

1. Remove old lens using a Phillip head screwdriver.
2. Locate the two Philips head screws on the lens.
3. Proceed by removing one screw at a time. Holding on to the lens as you remove screws. (Keep screws you will need them to reinstall new lens).
4. Clean any dirt or debris from turn signal housing.
5. Install lens on housing making sure to line up screws holes (hold lens in place). Using the two Phillips head screws you removed early, install one screw at a time. Do not over tighten screws this could cause the lens to crack.



Please read all Information below before Installation



ATTENTION



Safety First: Make sure the bike is parked on a level surface and bike 's mechanical components are cool to the touch.



Questions? Call us at: 1 (800) 382-1388 M-TH 8:30AM-5:30PM / FR 9:30AM-5:30PM EST