



Custom Dynamics® Magic Strobes™ Tour Pak® Brake Flasher Installation Instructions

We thank you for purchasing the Custom Dynamics® Magic Strobes™ Tour Pak® Brake Light Flasher! Our products utilize the latest technology and high quality components to ensure you the most reliable service. We offer one of the best warranty programs in the industry and we back our products with excellent customer support, if you have questions before or during installation of this product please call Custom Dynamics® at 1(800) 382-1388.

Part Number: MAGIC-STROBES-TP

Package Contents:

- Magic Strobes™ Brake Flasher (1)
- Tie Wraps (5)

Fits: 1997-2013 Harley-Davidson® Electra Glide® Ultra Classic/Limited Models, 2011-2013 Road Glide® Ultra & 2008-2013 Tri Glide® Models with King & Ultra Tour Pak® applies brake flash/strobe patterns to rear facing run/brake Tour-Pak® lights.

Does not fit OEM LED Tour-Pak® on CVO™ models.



⚠ ATTENTION ⚠

Please read all Information below before Installation

Important: Module must be secured after installation. Find safe area away from any moving parts and out of the way of normal operation of the bike. Use the enclosed tie-wraps to secure. Custom Dynamics® is not liable for damage as a result of improperly securing or failing to secure the module.

Important: Customers using this module with standard incandescent bulbs should use patterns 0-3 and 9. Any other settings selected will result in diminished performance. Converting to LEDs allows full use of programming options.

Caution: A stuck brake switch may cause this unit to overheat and fail. Unplug module immediately if this condition occurs.

Note: Although this device has been designed to significantly increase your braking visibility, flash/strobe patterns may not be street legal in your area. This device is not DOT approved.

Installation

1. Secure motorcycle on level surface.
2. Disconnect negative [-] battery cable from the battery.
3. Removing lining from Tour Pak®.
4. Locate connector in front left corner and unplug.
5. Plug the Magic Strobes™ module, in-line, into the Tour Pak® lighting harness and into the bike's wiring harness.
6. Re-connect the battery's negative battery cable to the negative [-] of the battery.
7. Select desired pattern on the dial with power Off. (See page 2 for pattern information)
8. Check operation.
9. To change pattern, turn bike OFF and change dial to desired pattern.
10. Locate a secure place for the Magic Strobes™ unit so that unit will not move. Secure with the enclosed tie-wraps. If you plan on changing settings periodically, select location that is easily accessible.
11. Re-install Tour Pak® lining.
12. Test function of Tour Pak® brake lights before riding.

Questions? Call us at: 1 (800) 382-1388 M-TH 8:30AM-5:30PM / FR 9:30AM-5:30PM EST

Installation Instructions - Page 2

Flash Pattern Information:

