



Custom Dynamics® Replacement Lenses Installation Instructions

We thank you for purchasing the Custom Dynamics® CD-TSLHK Replacement Lenses. Our products utilize the latest technology and high quality components to ensure you the most reliable service. We offer one of the best warranty programs in the industry and we back our products with excellent customer support, if you have questions before or during installation of this product please call Custom Dynamics® at 1(800) 382-1388.

Part Numbers:

CD-TSLHK-SMOKE
CD-TSLHK-RED
CD-TSLHK-CLEAR

Package Contents:

- Turn Signal Lenses (pair)
- Instructions



Fits: **Honda:** 2002-2005 VTX1800R/S/C & 2003-2009 VTX1300R/S/C/T Models, 2009-2017 Fury, 2010-2016 VT1300 Custom Line (Sabre, Stateline & Interstate), 2004-2017 Shadow 750 Aero/Phantom/RS, 2002-2003 Shadow Ace 750, 2001-2007 Shadow Sabre 1100 (Also Fits Most Other Honda Cruisers Replacing OEM Turn Signal Lens 33401-MBA-612)

Kawasaki: 2004-2010 Vulcan 2000, 2003-2008 Vulcan 1600 Classic/Nomad (Also Fits Other Kawasaki Cruisers Replacing OEM Turn Signal Lenses 23048-0001 or 23048-0002)



Please read all Information below before Installation

Warning: Disconnect negative battery cable from battery; refer to owner's manual. Failure to do so may result in electrical shock, injury, or fire. Secure negative battery cable away from positive side of battery and all other positive voltage sources on vehicle.

Safety First: Always wear appropriate safety gear including safety glasses when performing any electrical work. It is highly recommended that safety glasses be worn throughout this installation process. Be sure vehicle is on level surface, secure and cool.

Installation:

Locate and remove the factory lens attaching screw at the bottom of the turn signal housing. Retain screw for re-installation.



Carefully remove factory lens from housing by applying pressure to the attachment screw side of the lens and pulling out and upwards. Pay attention to the factory gasket ensuring the gasket does not fall out.



Using your fingers, remove thread clip from the factory lens and install on the new lens.



Verify the factory gasket is in place before installing new lens.



Align the thread clip of the new lens with factory mounting screw hole of the turn signal housing. Press into place until you hear a snap.



Install the factory mounting screw. Repeat installation for the other side.



NOTE: Clear or Smoke Lens must be used with Amber or Red bulb or LED.

Questions? Call us at: 1 (800) 382-1388 M-TH 8:30AM-5:30PM / FR 9:30AM-5:30PM EST