



## Custom Dynamics® Fender Tip Lens Installation Instructions

We thank you for purchasing the Custom Dynamics® Fender Tip Lens. Our products utilize the latest technology and highest quality components to ensure you the most reliable service. We offer one of the best warranty programs in the industry and we back our products with excellent customer support, if you have questions before or during installation of this product please call Custom Dynamics® at 1(800) 382-1388.

Part Numbers: **CFTF SFTF SFTR**

by **DRAG Specialties**

### Package Contents:

- Fender Tip Lens (1)



**Fits:** 1981-2013 Harley-Davidson® Electra Glide®, Ultra Classic, TriGlide® and Road King® Standard models, 1981-2017 Heritage Softail® models with OEM 194 front fender tip light bulb.



## ATTENTION



Please read all Information below before Installation

**Warning:** Disconnect negative battery cable from battery; refer to owner's manual. Failure to do so may result in electrical shock, injury, or fire. Secure negative battery cable away from positive side of battery and all other positive voltage sources on vehicle.

**Safety First:** Always wear appropriate safety gear including safety glasses when performing any electrical work. It is highly recommended that safety glasses be worn throughout this installation process. Be sure vehicle is on level surface, secure and cool.

### Installation:

1. Remove the old lens using a small flat head screw driver. Gently insert it between lens and fender tip light housing at the TOP center of the lens to depress the lens tabs down and gently ease the lens forward.
2. The lens has 2 small tabs on top and 1 larger tab on the bottom.
3. Install the new lens by inserting the single larger tab at the bottom of the lens into the bottom of fender tip housing.
4. Press the 2 smaller tabs against the top of the fender tip housing until they snap into place.
5. Verify the lens is seated correctly.



Questions? Call us at: 1 (800) 382-1388 M-TH 8:30AM-5:30PM / FR 9:30AM-5:30PM EST