



Custom Dynamics® LED Fender Tip Insert Installation Instructions

We thank you for purchasing the Custom Dynamics® LED Fender Tip Insert. Our products utilize the latest technology and highest quality components to ensure you the most reliable service. We offer one of the best warranty programs in the industry and we back our products with excellent customer support, if you have questions before or during installation of this product please call Custom Dynamics® at 1(800) 382-1388.

Part Numbers: GEN-FT-R-RUN, GEN-FT-W, GEN-FT-A

Package Contents:

- Single Intensity LED Fender Tip Insert (1)



Fitment: GEN-FT-A - 2013 and Earlier Touring (FLH*) and Heritage Softails®; 2014 Heritage Softail, 2015-Up Heritage Softail Classic

GEN-FT-W - 2013 and Earlier Touring (FLH*) and Heritage Softails®; Fits 2014 Heritage Softail, 2015-Up Heritage Softail Classic

GEN-FT-R-RUN - 2017 - Earlier Heritage Softail® Models, 2008 & Earlier Road King® Models, Electra Glide's®, and Ultra's® with stock OEM rear 194 bulb fender tip light.

Installation:

1. Remove lens using small flat head screwdriver
2. Remove stock 194 bulb from socket.
3. Ensure that the contacts are clean.
4. Place flat head screwdriver under bottom of socket and push up slightly for support.
5. Push new LED fender tip into socket using back and forth motion while supporting socket with screwdriver.

NOTE: It may be necessary to slightly bend the socket backwards towards the fender in order to get the lens back on with the LED Fender Tip Board.

6. Re-install lens.
7. Test Operation



ATTENTION



Please read all Information below before Installation

Warning: Disconnect negative battery cable from battery; refer to owner's manual. Failure to do so may result in electrical shock, injury, or fire. Secure negative battery cable away from positive side of battery and all other positive voltage sources on vehicle.

Safety First: Always wear appropriate safety gear including safety glasses when performing any electrical work. It is highly recommended that safety glasses be worn throughout this installation process. Be sure vehicle is on level surface, secure and cool.

Questions? Call us at: 1 (800) 382-1388 M-TH 8:30AM-5:30PM / FR 9:30AM-5:30PM EST