

Street Magic™ Billet Shifter Peg Cover

1. Remove rubber cover from stock shifter peg.
(Note: It may be easier to cut rubber for removal)
2. Cut off Mushroom head, remove any burrs.
3. Install Street Magic Shifter Cover and position into place.
4. Tighten 2 allen screws securely.

Street Magic™ Billet Shifter Peg Cover

1. Remove rubber cover from stock shifter peg.
(Note: It may be easier to cut rubber for removal)
2. Cut off Mushroom head, remove any burrs.
3. Install Street Magic Shifter Cover and position into place.
4. Tighten 2 allen screws securely.

Street Magic™ Billet Shifter Peg Cover

1. Remove rubber cover from stock shifter peg.
(Note: It may be easier to cut rubber for removal)
2. Cut off Mushroom head, remove any burrs.
3. Install Street Magic Shifter Cover and position into place.
4. Tighten 2 allen screws securely.

Street Magic™ Billet Shifter Peg Cover

1. Remove rubber cover from stock shifter peg.
(Note: It may be easier to cut rubber for removal)
2. Cut off Mushroom head, remove any burrs.
3. Install Street Magic Shifter Cover and position into place.
4. Tighten 2 allen screws securely.

Street Magic™ Billet Shifter Peg Cover

1. Remove rubber cover from stock shifter peg.
(Note: It may be easier to cut rubber for removal)
2. Cut off Mushroom head, remove any burrs.
3. Install Street Magic Shifter Cover and position into place.
4. Tighten 2 allen screws securely.

Street Magic™ Billet Shifter Peg Cover

1. Remove rubber cover from stock shifter peg.
(Note: It may be easier to cut rubber for removal)
2. Cut off Mushroom head, remove any burrs.
3. Install Street Magic Shifter Cover and position into place.
4. Tighten 2 allen screws securely.

