

## **Stryker LED Turn Signals**

- 1. Remove lens from turn signal housing.**
- 2. Remove bulb from turn signal housing.**
- 3. Remove Reflector**
- 4. Be sure contacts are clean.**
- 5. Insert base of LED cluster into housing, be sure it is fully seated**
- 6. Twist cluster to coil wire and insert cluster into housing.**
- 7. While holding cluster in place, reinstall lens.**
- 8. Check operation of turn signal in all modes.**

## **Strkyer LED Turn Signals**

- 1. Remove lens from turn signal housing.**
- 2. Remove bulb from turn signal housing.**
- 3. Remove Reflector**
- 4. Be sure contacts are clean.**
- 5. Insert base of LED cluster into housing, be sure it is fully seated**
- 6. Twist cluster to coil wire and insert cluster into housing.**
- 7. While holding cluster in place, reinstall lens.**
- 8. Check operation of turn signal in all modes.**

## **Strkyer LED Turn Signals**

- 1. Remove lens from turn signal housing.**
- 2. Remove bulb from turn signal housing.**
- 3. Remove Reflector.**
- 4. Be sure contacts are clean.**
- 5. Insert base of LED cluster into housing, be sure it is fully seated**
- 6. Twist cluster to coil wire and insert cluster into housing.**
- 7. While holding cluster in place, reinstall lens.**
- 8. Check operation of turn signal in all modes.**

## **Stryker LED Turn Signals**

- 1. Remove lens from turn signal housing.**
- 2. Remove bulb from turn signal housing.**
- 3. Remove Reflector.**
- 4. Be sure contacts are clean.**
- 5. Insert base of LED cluster into housing, be sure it is fully seated**
- 6. Twist cluster to coil wire and insert cluster into housing.**
- 7. While holding cluster in place, reinstall lens.**
- 8. Check operation of turn signal in all modes.**