



Custom Dynamics® TruBEAM® LED Headlamp Installation Instructions

We thank you for purchasing the Custom Dynamics® TruBEAM® LED headlamp! Our products utilize the latest technology and high quality components to ensure you the most reliable service. We offer one of the best warranty programs in the industry and we back our products with excellent customer support, if you have questions before or during installation of this product please call Custom Dynamics® at 1(800) 382-1388.

Part Number: CDTB-7-I-C CDTB-7-I-B

Package Contents:

- TruBEAM® LED Headlamp (1)
- Instructions

Fitment:

2015-2020 Indian® Chief® & Springfield® models, 2019-2020 Chieftain®, Chieftain® Dark Horse, Chieftain Elite, Chieftain® Limited and 2020 Roadmaster Dark Horse.

Custom Dynamics® plug and play Hi-Lo-Halo Adapter is required to enable internal DRL halo rings (sold separately).



Installation:

1. Disconnect the vehicle battery negative [-] terminal.
2. Review detailed service manual for instructions on replacing factory headlamp.
3. Remove the factory headlamp from vehicle.
4. Before installing TruBEAM®, locate the vent on the rear of the unit and remove the white plastic cover so that the vent will function properly.
5. Connect the TruBEAM® headlamp to the existing factory H4 plug and re-install according to your vehicles manual.
6. LED Halo (Optional): Locate the white wire on the back of the TruBEAM® headlamp. Power this wire by attaching it to the CDTB-HLA-1 adapter (sold separately). See adapters instructions for installation.




ATTENTION

Please read all Information below before Installation

Important: Due to the increased light output from this unit, it is recommended you take the vehicle to a dealer to have the headlamp properly adjusted. Weight and tire pressure can affect the position of the light.

Warning: To prevent possible electrical shock, disconnect the negative battery terminal before installing this product.



Questions? Call us at: 1 (800) 382-1388 M-TH 8:30AM-5:30PM / FR 9:30AM-5:30PM EST

Installation Instructions - Page 2

7. Re-assemble headlamp per the instructions in the detailed factory service manual. Make sure wires or any components of the harness can not be pinched during installation and that they will not be exposed to water spray, excessive heat or moving parts.
8. Re-connect vehicle battery negative [-] terminal.
9. Test function of headlamp for high beam and low beam function:
 - Stock function without CDTB-HLA-1 = When low beam is ON, high beam is OFF, when high beam is ON, low beam is OFF. Halo will not illuminate.
 - Function when using CDTB-HLA-1 = When low beam is ON, high beam is OFF. When high beam is ON, low beam is ON.
 - Halo Function = Halo will only work if connected running power is applied to the white wire. Function is optional.

