ProBEAM® Flat Style Turn Signal Lenses Installation Instructions

1. Confirm large O-ring is properly seated along edge of provided turn signal lens.
2. Place 1 small rubber washer (provided) on each OEM turn signal screw. Install lens.
3. Confirm lens is installed correctly to prevent excess moisture or water from entering the turn signal housing.

ProBEAM® Flat Style Turn Signal Lenses Installation Instructions

1. Confirm large O-ring is properly seated along edge of provided turn signal lens.
2. Place 1 small rubber washer (provided) on each OEM turn signal screw. Install lens.
3. Confirm lens is installed correctly to prevent excess moisture or water from entering the turn signal housing.

ProBEAM® Flat Style Turn Signal Lenses Installation Instructions

1. Confirm large O-ring is properly seated along edge of provided turn signal lens.
2. Place 1 small rubber washer (provided) on each OEM turn signal screw. Install lens.
3. Confirm lens is installed correctly to prevent excess moisture or water from entering the turn signal housing.

ProBEAM® Flat Style Turn Signal Lenses Installation Instructions

1. Confirm large O-ring is properly seated along edge of provided turn signal lens.
2. Place 1 small rubber washer (provided) on each OEM turn signal screw. Install lens.
3. Confirm lens is installed correctly to prevent excess moisture or water from entering the turn signal housing.

ProBEAM® Flat Style Turn Signal Lenses Installation Instructions

1. Confirm large O-ring is properly seated along edge of provided turn signal lens.
2. Place 1 small rubber washer (provided) on each OEM turn signal screw. Install lens.
3. Confirm lens is installed correctly to prevent excess moisture or water from entering the turn signal housing.

ProBEAM® Flat Style Turn Signal Lenses Installation Instructions

1. Confirm large O-ring is properly seated along edge of provided turn signal lens.
2. Place 1 small rubber washer (provided) on each OEM turn signal screw. Install lens.
3. Confirm lens is installed correctly to prevent excess moisture or water from entering the turn signal housing.

ProBEAM® Flat Style Turn Signal Lenses Installation Instructions

1. Confirm large O-ring is properly seated along edge of provided turn signal lens.
2. Place 1 small rubber washer (provided) on each OEM turn signal screw. Install lens.
3. Confirm lens is installed correctly to prevent excess moisture or water from entering the turn signal housing.

ProBEAM® Flat Style Turn Signal Lenses Installation Instructions

1. Confirm large O-ring is properly seated along edge of provided turn signal lens.
2. Place 1 small rubber washer (provided) on each OEM turn signal screw. Install lens.
3. Confirm lens is installed correctly to prevent excess moisture or water from entering the turn signal housing.

ProBEAM® Flat Style Turn Signal Lenses Installation Instructions

1. Confirm large O-ring is properly seated along edge of provided turn signal lens.
2. Place 1 small rubber washer (provided) on each OEM turn signal screw. Install lens.
3. Confirm lens is installed correctly to prevent excess moisture or water from entering the turn signal housing.

ProBEAM® Flat Style Turn Signal Lenses Installation Instructions

1. Confirm large O-ring is properly seated along edge of provided turn signal lens.
2. Place 1 small rubber washer (provided) on each OEM turn signal screw. Install lens.
3. Confirm lens is installed correctly to prevent excess moisture or water from entering the turn signal housing.