



## Rider's Claw Assembly Instructions



Remove upper and lower torque screws from clutch/cable bracket.



Assemble Back Plate, Stand Offs (2), and 1/4-20 x 1 3/4" (2) Button Head Screws (Note pictures below to insure the button head screws rest inside counter bores and the stand offs are flush to flat side of the back plate).



Secure Back Plate to clutch/mirror bracket with Allen wrench



Assemble 10-32 x 1/2" Flat Head Screws into Rider's Claw



Secure Rider's Claw to Back Plate with Allen wrench.