

Street Magic® Cycle Products

Metric/Universal/V-Rod Signal Stabilizer™ Installation Instructions

Fits All Metric Models Except Can Bus

1. Locate wires going to rear directional lights. If a Run- Brake-Turn module is installed, Signal Stabilizer must go before Run-Brake-Turn module.
2. Attach Purple wire from Signal Stabilizer™ unit to left side rear directional wire using Posi-Tap connectors supplied with kit.
3. Attach Brown wire from Signal Stabilizer™ unit to Right side rear directional wire using Posi-Tap connectors supplied with kit.
4. Attach Red wire from Signal Stabilizer™ to POSITIVE of battery through the 3 amp Fuse.
5. Attach Black wire with terminal ring from Signal Stabilizer™ to NEGATIVE of battery.
6. Attach remaining Black wire from Signal Stabilizer™ to a ground but not the Negative of battery using supplied Posi Tap
7. Test signals for proper operation.
8. Test Alarm, if equipped, for proper operation.




Street Magic® Cycle Products

Signal Stabilizer™ Installation Instructions


Posi-Tap Instructions

Posi-Tap™





TAP CONNECTOR





- TAPS WIRES WITHOUT CUTTING
- TOTAL WIRE INTEGRITY IS MAINTAINED
- INSTALLS IN SECONDS BY HAND
- NO CRIMPING OR TOOLS REQUIRED
- REUSABLE OR PERMANENT
- LESS RESISTANCE
- VIBRATION PROOF
- FULLY INSULATED




QUICK & EASY

- **1** Insert Hot Wire
- **2** Tighten
- **3** Strip Leads
- **4** Insert & Tighten



NO CRIMPING



NO TOOLS NEEDED