



Custom Dynamics® ProGLOW™ Wheel Light Installation Instructions

We thank you for purchasing the Custom Dynamics® ProGLOW™ Wheel Light. Our products utilize the latest technology and high quality components to ensure you the most reliable service. We offer one of the best warranty programs in the industry and we back our products with excellent customer support, if you have questions before or during installation of this product please call Custom Dynamics® at 1(800) 382-1388.

Part Numbers: PG-WL-B PG-WL-C

Package Contents:

-ProGLOW™ Wheel Light (1)

Fits: All Harley-Davidson® Brake Calipers (except: narrow glide front ends, Sportsters®, some Dynas®, and 2006-2017 V-Rods). Metric bikes where the back side of the brake caliper is flat and there is 5/8" clearance between the caliper and wheel.

Compatible with ProGLOW™ Bluetooth Remote Control



ATTENTION


Please read all Information below before Installation

Warning: Disconnect negative battery cable from battery; refer to owner's manual. Failure to do so may result in electrical shock, injury, or fire. Secure negative battery cable away from positive side of battery and all other positive voltage sources on vehicle.

Safety First: Always wear appropriate safety gear including safety glasses when performing any electrical work. It is highly recommended that safety glasses be worn throughout this installation process. Be sure vehicle is on level surface, secure and cool.

Important: This product is designed and intended for use as auxiliary lighting only. It is NOT intended to replace any original equipment lighting installed on the vehicle and should not be used for that purpose. This product must be wired so that it does not interfere with any original equipment lighting.

Important: Ambient install temperature must be 60 degrees F or higher. Allow 24 hours for tape to cure before washing or prolonged use of vehicle.



Installation:

1. Verify that there is enough clearance between the back of brake caliper and the wheel to mount the ProGLOW™ Wheel Light.
2. Clean the mounting area on the back side of the brake caliper with denatured alcohol, allow to dry.
3. Mount the ProGLOW™ Wheel Light on the back side of the brake caliper. Spin the wheel to confirm the wheel will not make contact with the wheel light.
4. Route the wiring harness of the wheel light back to the ProGLOW® Bluetooth Controller. Route wires such that they not interfere with normal operation of bike.
5. Once wiring has been completed, secure any remaining wires with tie wraps (not included).
6. Power the ProGLOW Bluetooth Controller (sold separately) OFF and connect the wheel light harness to one of the controller channels. Use caution when connecting the mating ProGLOW™ Wheel Light connector, confirm the mating connector is connected correctly or damage will occur to the lighting accessories. The locking tab should slide onto the lock and lock into position. See Photo 1.
7. Power up the ProGLOW™ Bluetooth Controller and test the wheel light for proper operation.

Questions? Call us at: 1 (800) 382-1388 M-TH 8:30AM-5:30PM / FR 9:30AM-5:30PM EST