



## Custom Dynamics® Genesis® 4 LED

### Turn Signal Installation Instructions

We thank you for purchasing the Custom Dynamics® Genesis® 4 LED Turn Signals. Our products utilize the latest technology and high quality components to ensure you the most reliable service. We offer one of the best warranty programs in the industry and we back our products with excellent customer support, if you have questions before or during installation of this product please call Custom Dynamics® at 1(800) 382-1388.

**Part Numbers:** GEN-4-R-1156

**Package Contents:**

- Genesis 4 Red LED Clusters (1 pair)

**Fits:** Rear turn signals on Harley-Davidson® Models with 1156 single contact bases and Bullet Style (Pop-off) lens.  
**NOTE:** Custom Dynamics® smoked, red or clear motorcycle turn signal lens (sold separately) required for proper installation. OEM lenses are not compatible



Please read all Information below before Installation

**Warning:** Disconnect negative battery cable from battery; refer to owner's manual. Failure to do so may result in electrical shock, injury, or fire. Secure negative battery cable away from positive side of battery and all other positive voltage sources on vehicle.

**Safety First:** Always wear appropriate safety gear including safety glasses when performing any electrical work. It is highly recommended that safety glasses be worn throughout this installation process. Be sure vehicle is on level surface, secure and cool.

**NOTE:** DOT Compliant when used behind Custom Dynamics® smoked, red, or clear motorcycle turn signal lens (sold separately).

**NOTE:** They will not function properly in the front. For proper color output, use a smoked, red, or clear lens.

**Important Tips and Troubleshooting:**

1. Dielectric grease does not need to be used with this LED product, it can actually prevent them from working.
2. If you experience issues with function, clean the bottom contacts, then re-insert. Also, try in the other turn signal socket.
3. If you experience fast flashing from your turn signals after installation, you may need a load equalizer or our Smart Signal Stabilizer™. Contact us for details.
4. This LED Product is BCM Compliant. If installing on 2011 and newer Softails®, 2012 and newer Dynas®, or any 2014 & newer model Harley Davidson®, it is recommended to run the 4 way hazards for 5 minutes to re-sync the CanBus system. No load equalizer or Smart Signal Stabilizer™ is needed for these models.

#### Installation:

1. Remove lens from turn signal housing.
2. Remove bulb from turn signal housing.
3. Remove any corrosion or dielectric grease from the socket contacts.
4. Insert the base into the socket. If it seems hard to twist the base in the socket or hard to remove, it is probably orientated the wrong way.
5. Twist the LED turn signal a few rotations to coil wire from the turn signal to the socket base. Insert LED turn signal into housing and install new Custom Dynamics® lens.
6. Check operation of turn signal in all modes.