



## Custom Dynamics® Run/Brake/Turn Accessory Adapter For Harley-Davidson® Installation Instructions


We thank you for purchasing the Custom Dynamics® Run/Brake/Turn Accessory Adapter For Harley-Davidson®. Our products utilize the latest technology and high quality components to ensure you the most reliable service. We offer one of the best warranty programs in the industry and we back our products with excellent customer support, if you have questions before or during installation of this product please call Custom Dynamics® at 1(800) 382-1388.

**Part Numbers:** MPR-SS6-EPZ-PLUG

**Package Contents:**

- MPR Adapter Harness (1)

**Fits:** 2010-2013 Street Glide®, 2010-2013 Road Glide® Custom (Does not Fit CVO™ Models)



Please read all Information below before Installation

**Warning:** Disconnect negative battery cable from battery; refer to owner's manual. Failure to do so may result in electrical shock, injury, or fire. Secure negative battery cable away from positive side of battery and all other positive voltage sources on vehicle.

**Safety First:** Always wear appropriate safety gear including safety glasses when performing any electrical work. It is highly recommended that safety glasses be worn throughout this installation process. Be sure vehicle is on level surface, secure and cool.

**Important:** This product is designed and intended for use as auxiliary lighting only. It is NOT intended to replace any original equipment lighting installed on the vehicle and should not be used for that purpose. This product must be wired so that it does not interfere with any original equipment lighting.

### Installation:


1. Remove the left side cover, locate and unplug the rear lighting connector to the rear fender.
2. Connect the MPR Adapter Harness in-line with the rear lighting harness and main wiring harness. If installing with a Run/Brake/Turn module, install the MPR Adapter harness after the main wiring harness connector and in front of the Run/Brake/Turn module.  
**Note:** The Red wire extension is only used for brake strobe applications. See wiring diagram on Page 2 if installing with a SMART Triple Play® module with brake strobe.
3. Connect the 3 pin connectors from the lights to the 3 pin connectors on the MPR Adapter harness. The Male connector with the Purple wire connects to the Female connector of the light with the Purple wire. The Male connector with the Brown wire connects to the Female connector of the light with the Brown wire.
4. Reinstall the left side cover. Test all lighting for proper operation before riding.

Questions? Call us at: 1 (800) 382-1388 M-TH 8:30AM-5:30PM / FR 9:30AM-5:30PM EST

# Brake Strobe Modification

This modification will allow lights to strobe for brake when used with a SMART Triple Play® module (Sold Separately).

The YELLOW jumper wire in the MPR Adapter Harness must be cut and capped. The long single Red wire will need to be connected to the brake output wire of the SMART Triple Play® module.



Questions? Call us at: 1 (800) 382-1388 M-TH 8:30AM-5:30PM / FR 9:30AM-5:30PM EST